

ENERGY TECHNOLOGIES  
BUILD LIFE BETTER

RESIDENTIAL  
BATTERY



## MANA 16.0

### Product Description

#### Contact Details

Shenzhen EEnovance Energy Technology CO., LTD

Room 401, Building 2, Yufengda Industrial Park, No. 1008  
Guangqiao Avenue, Yulv Community, Yutang Streets,  
Guangming District, SHENZHEN.PRC.

Telephone: +86 755 8656 6313

Email: [info@eenovance.com](mailto:info@eenovance.com)

Copyright@2024 Shenzhen EEnovance Energy Technology Co., Ltd. All rights reserved.  
EN V1.3 202512

**EENOVANCE**

[eenovance.com](http://eenovance.com)

# CONTENTS

<b>1 Technical Data .....</b>	<b>1-2</b>
<b>2 Product Overview .....</b>	<b>3</b>
2.1    Brief Introduction .....	3
2.2    Interface Introduction .....	4
2.2.1    Switch ON / OFF .....	4
2.2.2    LED Indicator Definition .....	5-6
2.2.3    CAN / RS485 Port .....	7
2.2.4    RS232 Port .....	7
<b>3 Installation Guide .....</b>	<b>8</b>
3.1    Checking Before Installation .....	8
3.1.1    Checking Outer Packing Materials .....	8
3.1.2    Checking Deliverables .....	8-9
3.2    Tools .....	10
3.3    Installation Requirements .....	10
3.3.1    Installation Environment Requirements .....	10
3.3.2    Installation Carrier Requirements .....	10
3.4    Installation Instructions .....	11
3.4.1    Dimensions .....	11
3.4.2    Installation Procedure .....	12-15
<b>4 Maintenance .....</b>	<b>16</b>
4.1    Recharge Requirements During Normal Storage .....	16
4.2    Recharge Requirements When Over Discharged .....	16
<b>5 Disposal Of The Battery System .....</b>	<b>17</b>

# 01 TECHNICAL DATA

## NOTE

The battery is not rated 1C continuously. Operating current derating according to the cell voltage and battery temperature.

### Safe and Reliable

Meet diverse home energy needs with LFP batteries that last up to 6,000 cycles, ensuring safety and reliability.

### Flexible and Expandable

Easily connect up to 15 units in parallel, don't worry about future power increases in your home.

### Hassle-Free Setup

Easily choose between floor or wall installation, and effortless maintenance.

### Smart Home

Use your smartphone to control your home energy freely.



## Datasheet

Model	MANA 16.0
-------	-----------

### Performance

Cell technology	LFP ( LiFePO4)
Battery usable energy [1]	15.970 kWh
Nominal voltage	51.2 Vdc
Operating voltage	44.8 - 56.16 Vdc
Max. charge and discharge current [2]	300 A

### Communication

Display	SOC status indicator, LED indicator
Communication	CAN / RS485 / RS232 / Wi-Fi

### General Specification

Dimension (W×D×H)	720×160×916 mm 28.3×6.3×36.1 inch
Weight	130 kg (286.6 lbs)
Installation	Floor stand or wall mounted
Operating temperature [3]	Charge : 0 to 50°C (32 to 122°F) Discharge: -15 to 50°C (5 to 122°F)
Environmental humidity	≤ 95%RH (No condensation)
Ingress protection rating	IP 20
Cycle life [4]	6000 Cycles or ten (10) years @ 80% DOD / 25°C / 0.5C, 70% EOL
Scalability	Max 15 batteries in parallel
Application	ON Grid / ON Grid + Backup / OFF grid
Compatible inverters	Refer to compatible inverter list (Compatible with major PCS brands)

### Standard Compliance

Compliance	UN38.3 / IEC62619 / IEC61000 (More available upon request)
------------	--

### Ordering and Deliverable Part

Part	MANA 16.0 Battery
	MANA 16.0 Parallel cable
	MANA 16.0 to PCS cable

[1] Test conditions: 100% depth of discharge (DOD), 0.2C rate charge & discharge at 25°C.


[2] There is 0.5C or 1C configurations optional in factory default.

[3] Charge/discharge derating occurs when the temperature is below 0°C or above 45°C.

[4] Please refer to the Warranty Letter for applicable conditions, the warranty is due whichever comes first.

# 02 PRODUCT OVERVIEW

## 2.1 Brief Introduction




PRODUCT OVERVIEW

MANA 16.0 is a lithium battery with an operating voltage range between 44.8-56.16V. It is designed for residential energy storage applications and works together with a 48V battery hybrid inverter. MANA 16.0 is not suitable for supporting life-sustaining medical devices.

MANA 16.0 has built-in BMS (Battery Management System), which can manage and monitor cells information including voltage, current and temperature. Besides that, BMS can balance cells charging to extend cycle life. BMS has protection functions including over-discharge, over-charge, over-current and high/low temperature; the system can automatically manage charge state, discharge state and balance state.

Multiple MANA 16.0 can be connected in parallel to expand capacity and power, 15 MANA 16.0 can be connected in parallel at most.

## 2.2 Interface Introduction



Operation interface description:

Serial Number	Name	Description
1	ON / OFF button	Start-up switch
2	Status Indicator	Operation, alarm, and SOC status
3	Slide switch	BMS power supply switch
4	Rocker switch	BMS switch
5	Air Switch	Output switch
6	Positive terminal	Total positive terminal
7	Negative terminal	Total negative terminal
8	Communication port	Communication interface
9	WiFi interface	Port for WiFi

### 2.2.1 Switch ON / OFF

#### 1. Switch ON

For single MANA 16.0, switch ON rocker switch (near positive / negative connector), then long press (more than 3 seconds) ON / OFF button on front panel, LED will flash then battery will operate normally. L1 to L6 shows battery SOC, L7 / L8 shows battery status.

For multiple MANA 16.0 in parallel, switch ON rocker switch on all batteries, long press (more than 3 seconds) ON / OFF button of MASTER battery, LED will flash, battery system will automatically encode and assign ID to each slave battery, then battery system will operate normally.

## 2. Switch OFF

Press start button of Master PACK more than 3s and then release the button, the master pack will shut down after all slave packs shut down (Sleep mode)

For single MANA 16.0, switch OFF rocker switch (near positive / negative connector).

For multiple MANA 16.0 in parallel, switch OFF rocker switch on all slave batteries first.

Then switch OFF rocker switch on MASTER battery.

## 2.2.2 LED Indicator Definition

Note:

flash 1 - 0.25s light / 3.75s off

flash 2 - 0.5 light / 0.5s off

flash 3 - 0.5s light / 1.5s off

### LED Indicators Instructions

	RUN	ALM	Battery Level Indicator								
Status	L8	L7	L6	L5	L4	L3	L2	L1	Descriptions		
Shut down	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	All OFF		
Standby	Flash 1	OFF	According to the battery level					Indicates Standby			
Charging	Normal	Light	OFF	According to the battery level					The highest capacity indicator LED flashes(flash 2),others lighting		
	Full Charged	Light	OFF	Light	Light	Light	Light	Light	Turn to standby status when charger off		
Discharge	Protection	OFF	Light	OFF	OFF	OFF	OFF	OFF	Stop charging		
	Normal	Flash 3	OFF	According to the battery level							
	UVF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Stop charging		
	Protection	OFF	Light	OFF	OFF	OFF	OFF	OFF	Stop discharge		
Fault	OFF	Light	OFF	OFF	OFF	OFF	OFF	OFF	Stop charging and Discharge		

### Charging / Battery Level Indicators Instructions

Status		Charging							
Battery Level Indicator		L8	L7	L6	L5	L4	L3	L2	L1
Battery Level (%)	0~17%	Light	OFF	OFF	OFF	OFF	OFF	Flash 2	
	18~33%			OFF	OFF	OFF	OFF	Flash 2	Light
	34~50%			OFF	OFF	OFF	Flash 2	Light	Light
	51~66%			OFF	OFF	Flash 2	Light	Light	Light
	67~83%			OFF	Flash 2	Light	Light	Light	Light
	84~100%			Flash 2	Light	Light	Light	Light	Light
	Full Charged			Light	Light	Light	Light	Light	Light

### Discharging Battery Level Indicators Instructions

Battery Level Indicator	Discharge							
	L8	L7	L6	L5	L4	L3	L2	L1
Battery Level (%)	0~17%	OFF	OFF	OFF	OFF	OFF	OFF	Light
	18~33%	OFF	OFF	OFF	OFF	OFF	Light	Light
	34~50%	OFF	OFF	OFF	OFF	Light	Light	Light
	51~66%	OFF	OFF	Light	Light	Light	Light	Light
	67~83%	OFF	Light	Light	Light	Light	Light	Light
	84~100%	Light						

### Protection Fault Indicators Instructions

Status	Protection Fault							
	L8	L7	L6	L5	L4	L3	L2	L1
Status Battery Level Indicator	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Battery Level (%)	84 ~ 100%	67 ~ 83%	51 ~ 66%	34 ~ 50%	18 ~ 33%	0 ~ 17%		
	Cell failure	OFF	OFF	OFF	OFF	OFF	OFF	OFF
	NTC failure	Light	OFF	OFF	OFF	OFF	OFF	OFF
	Precharge failure	OFF	Light	OFF	OFF	OFF	OFF	OFF
	Short circuit fault	Light	Light	OFF	OFF	OFF	OFF	OFF
	Charging MOS failure	OFF	OFF	Light	OFF	OFF	OFF	OFF
	Discharge MOS fault	Light	OFF	Light	OFF	OFF	OFF	OFF
	Precharge failure	OFF	Light	Light	OFF	OFF	OFF	OFF
	Total negative contact failure	Light	Light	Light	OFF	OFF	OFF	OFF
	Overvoltage protection of charging cells	OFF	OFF	OFF	Light	OFF	OFF	OFF
	Overall charging overvoltage protection	Light	OFF	OFF	Light	OFF	OFF	OFF
	Charging overcurrent protection	OFF	Light	OFF	Light	OFF	OFF	OFF
	Discharge cell undervoltage protection	Light	Light	OFF	Light	OFF	OFF	OFF
	Discharge overall undervoltage protection	OFF	OFF	Light	Light	OFF	OFF	OFF
	Discharge overcurrent protection	Light	OFF	Light	Light	OFF	OFF	OFF
Environmental Protection	Charging high temperature protection	OFF	Light	Light	Light	OFF	OFF	OFF
	Charging low temperature protection	Light	Light	Light	Light	OFF	OFF	OFF
	High temperature protection for discharge	OFF	OFF	OFF	OFF	Light	OFF	OFF
	Discharge low temperature protection	Light	OFF	OFF	OFF	Light	OFF	OFF
	MOS tube high temperature protection	OFF	Light	OFF	OFF	Light	OFF	OFF
	Environmental low temperature protection	Light	Light	OFF	OFF	Light	OFF	OFF
	Ambient high temperature protection	OFF	OFF	Light	OFF	Light	OFF	OFF

Notes: 1. The fault lamp ALM is not on in normal state, at this time the SOC lamp is used as a power indication, the fault lamp ALM is always on when the fault occurs, the SOC lamp is on according to the fault sequence number (priority sequence number from low light), if a variety of protection faults exist, the RUN lamp also needs to be on constantly.

## 2.2.3 CAN / RS485 Port

CAN/ RS485 Communication Terminal (RJ45 port), connects to inverter, and follows CAN / RS485 protocol.

PIN	Definition
Pin 1, Pin 8	RS485-B (to Inverter, reserved )
Pin 2, Pin 7	RS485-A (to Inverter, reserved)
Pin 3	NC
Pin 4	CANH (to Inverter)
Pin 5	CANL (to Inverter)
Pin 6	GND


## 2.2.4 RS232 Port

RS232 Communication Terminal (RJ45 port) follows RS232 protocol, for manufacturers or professional engineers to debug or service.

PIN	Definition
Pin 1, Pin 8	GND
Pin 2, Pin 7	RS232_TX
Pin 3, Pin 6	RS232_RX
Pin 4, Pin 5	NC

# 03 INSTALLATION GUIDE

## Installation flow chart



## 3.1 Checking Before Installation


### 3.1.1 Checking Outer Packing Materials

Packing materials and components may be damaged during transportation. Therefore, check the outer packing materials before installing the battery. Checking the surface of packing materials for damage, such as holes and cracks. If any damage is found, do not unpack the battery and contact the dealer as soon as possible. You are advised to remove the packing materials within 24 hours before installing the battery.

### 3.1.2 Checking Deliverables

After unpacking the battery, check whether deliverables are intact and complete. If any damage is found or any component is missed, contact the dealer.

The below table shows the components and mechanical parts that should be delivered.



NO.	Pictures	Quantity	Description
1		1PCS	Battery
2		1PCS	Wall bracket
3		2PCS	Hanging bracket
4		1PCS	Supporting structure
5		4PCS	M10*80
6		12PCS	M6*16
7		2PCS	M4*20
8		1PCS	Test report
9		1PCS	QA certificate

### 3.2 Tools

Model	Tools		
Installation			
Protection			

### 3.3 Installation Requirements

#### 3.3.1 Installation Environment Requirements


- Install the battery in the indoor environment.
- Place battery in secure location away from children and animals.
- Do not place the battery near any heat sources and avoid sparks.
- Do not expose the battery to moisture or liquids.
- Do not expose the battery to direct sunlight.

#### 3.3.2 Installation Carrier Requirements


- Only mount battery on fire resistant building. Do not install batteries on flammable buildings.
- Battery is quite heavy, make sure the wall/ground can meet the load bearing requirements.

## 3.4 Installation Instructions

### 3.4.1 Dimensions




Minimum mounting distance between battery pack and equipment:



### 3.4.2 Installation Procedure

#### STEP 1


Drill the hole with an 12mm drill bit as follows and fix the wall bracket to the wall.



The bearing capacity of the wall is greater than 150kg


#### STEP 2

Install the hanging bracket and support plate.




**STEP 3**


Use a crane to lift the ring on the battery pack and attach it to the wall bracket.

**STEP 4**


Connect to ground.

**STEP 5**

Connect power cable.

**STEP 6**



Connect communication cable.



**STEP 7**

When multiple batteries are connected in parallel, follow the following wiring mode.

Parallel Cables length 1000mm; Power Cables length 1500mm.

**SCHEME ONE****SCHEME TWO****04 MAINTENANCE****4.1 Recharge Requirements During Normal Storage**

Battery should be stored in an environment with temperature range between -10°C ~ +45°C, and maintained regularly according to following table with 0.5C (150A) current till 40% SOC after long storage time.

**Recharge Conditions When In Storage**

Storage Environment Temperature	Relative Humidity of Storage Environment	Storage Time	SOC
Below -10°C	/	Prohibit	/
-10~25°C	5%~70%	≤12 months	30%≤SOC≤60%
25~35°C	5%~70%	≤6 months	30%≤SOC≤60%
35~45°C	5%~70%	≤3 months	30%≤SOC≤60%
Above 45°C	/	Prohibit	/

**4.2 Recharge Requirements When Over Discharged**

Over discharged (90% DOD) battery should be recharged according to following table, otherwise over discharged battery will be damaged.

**Recharge conditions when battery is over discharged**

Storage Environment Temperature	Storage Time	Note
-10~25°C	≤15 days	Battery Pack disconnected from Inverter
25~35°C	≤7 days	
-10~45°C	<12 hours	Battery Pack connected to Inverter

## 05 DISPOSAL OF THE BATTERY SYSTEM

Disposal of the battery must comply with the local applicable disposal regulations for electronic waste and used batteries.

- Do not dispose of the battery system with your household waste.
- Avoid exposing the batteries to high temperatures or direct sunlight.
- Avoid exposing the batteries to high humidity or corrosive atmospheres.